



## Filter, Innenraumluft

### Hinweis:

Der Innenraumluftfilter befindet sich im Wagennieren, in Fahrtrichtung rechts hinter dem Handschuhfach.

### Ausbau:

Das Handschuhfach öffnen und durch Eindrücken der Seiten aus der Halterung nehmen.

(Abb. 1)




Abb. 1

Die Abdeckung des Innenraumluftfilterkastens entfernen und die Filter nacheinander entnehmen.

(Abb. 2, 3)




Abb. 2

### Einbau:

Der Einbau erfolgt in umgekehrter Reihenfolge des Ausbaus.

### Auf richtigen Sitz des Filterelements achten!

### Bitte umweltfreundliche Entsorgung des Altteils gewährleisten!

Dieser Einbauhinweis ersetzt nicht die Angaben des Fahrzeugherstellers. Die originalen Hinweise sind daher dringend zu beachten!




Abb. 3

Abbildung ähnlich!





## Filter, Cabin Air


### Note:

The cabin air filter is installed inside the car at the right side behind the glove box.

### Filter Replacement:

Open the glove box and detach it by pushing the sides together.


(pict. 1)



pict. 1

Remove the cover of the cabin air filter case and take out the filters one by one.

(pict. 2, 3)



pict. 2

The installation is done in reverse sequence of replacement.

### Take care about correct fitting of the filter!

### Please think about the environment when you throwing away the old filter!



pict. 3

This fitting instructions are declared without commitment and should be used as a substitute for the manufacturer instructions.

Similar to original!

