



**Anziehvorschrift Zylinderkopf****Tightening Instructions for Cylinder Head****Instructions de serrage pour culasse****Prescripciones de apriete para culatas****777.750**passend für / suitable for  
adaptable à / adaptable a**Ford****Das Original**Schraubenkopf / Head shape    Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo

175.580

M 10x159,5/M8x121

Anziehen/  
Tightening/  
Serrage/  
Apriete

- ⊙ 10 Nm (1-12 M10)
- ⊙ 5 Nm (13-22 M8)
- ⊙ 20 Nm (1-12 M10)
- ⊙ 10 Nm (13-22 M8)
- ⊙ 50 Nm (1-12 M10)
- 180° (1-12 M10)
- 25 Nm (13-22 M8)
- 180° (13-22 M8)

Zeichenerklärung / Explanations / Explication / Explicacion

	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
*	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Ø: 91,0 mm; ÷ 1,10 mm; 1 Loch/notch

Mot: SAFA;SAFB

3,2 ltr TDCi

Transit 09.07 - 08.14

**Elring-Serviceteam**

Fon +49 7123 724 799

Fax +49 7123 724 798

service@elring.de

24/01/22

**\*777.750\***