

Montageanleitung | Installation Instruction | Notice de montage

Istruzioni di montaggio | Instrucciones de montaje

Instruções de montagem | Installationsanvisning | Montagehandleiding

de Innenraumfilter

en Cabin filter

fr Filtre d'habitacle

it Filtro abitacolo

es Filtro ventilación para interior

pt Filtro de cabine


sv Kupéfilter

nl Interieurfilter

6000161909



BOSCH



0 986 628 661

Volvo V70 III

08.07-->

Volvo S80 II

07.06-->

Volvo XC60

10.08-->

Land Rover Freelander II

01.07 -->

Land Rover Evoque [L538, L551]

09.11 -->

Jaguar E-Pace

09.17 --> 08.20

