

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

Chevrolet Cruze (J300)  
Chevrolet Volt  
Chevrolet Malibu  
Chevrolet Orlando  
OPEL Ampera  
OPEL Astra J + Sports Tourer  
OPEL Insignia  
OPEL Meriva B  
OPEL Mokka  
OPEL Zafira III

80001185

80001186

05.09. →

11.11. →

01.12. →

12.10. →

11.11. →

12.09. →

07.08 →

06.10. →

06.12. →

01.11. →



The Perfect Change.

10-20 min

