

Einbauanleitung  
Fitting instructions  
Istruzioni di montaggio  
Notice de montage  
Instrucciones de montaje  
Monteringsanvisning

**CORTECO**

80004403

VW UP  
SEAT Mii  
SKODA Citigo

12.11 ->  
04.12 ->  
04.12 ->



The Perfect Change.

