

- Ⓓ Wechselintervall alle ...
- ⒼⒷ Replacement interval ...
- Ⓘ Sostituzione dopo ...
- Ⓕ Intervalle de remplacement ...
- Ⓔ Intervalle de cambio ...
- ⒹⒻ Vervanging elke ...

15.000 KM /

10.000 MI

- Ⓓ ... oder nach 1 Jahr
- ⒼⒷ ... or after 1 year
- Ⓘ ... or dopo 1 anno
- Ⓕ ... ou 1 fois par an
- Ⓔ ... o después de 1 ano
- ⒹⒻ ... of 1 keer per jaar

Ford Fiesta V 11.01 →
Ford Fusion 03 →

21652858 / CC1097 / MC 614
21652857 / CP1097 / MP 114

Einbauanleitung

Innenraumfilter

Fitting instructions

Cabin air filter

Istruzioni di montaggio

Filtro abitacolo

Notice de montage

Filtre d'habitacle

Instrucciones de montaje

Filtro de habitáculo

Inbouwhandleiding

Interieurfilter

