

Fitting instructions for ABS ring

Manufacturer: SAF

Axle type: SK RB 9019 WI INTEGRAL
SK RB 9022 WI INTEGRAL
SK RB 9022 KI INTEGRAL
SK RB 9019 KI INTEGRAL

Part No.: 569868.H195
Repair Insert Unit (RIU)

OE-No.: 04 200 1019 00 (bearing)



Figure 1: Fitting ABS Ring

FAG is supplying a new repair insert unit (RIU) for SAF applications for the aftermarket. The RIU comprises of an inner and outer bearing, a mounting tool and an ABS Ring complete with it's fitting tool, as it is likely to be damaged during disassembly and needs to be replaced.

Procedure:

- Ensure the seat of the ABS ring is clean before fitting the new RIU
- Position the ABS ring on the hub
- Position the supplied mounting tool on the ABS ring
- Insert a metal plate between the punch and the mounting tool to protect it
- Using a suitable tool, press on the ABS ring (max. 10 KN)

FAG AM scope of supply:

- 1 x RIU
- 1 x mounting tool for the RIU
- 1 x ABS ring
- 1 x mounting tool for ABS ring



Note the specifications of the vehicle manufacturer!

Appropriate spare parts can be found in our on-line catalogue at www.Schaeffler-Aftermarket.com or in RepXpert at www.RepXpert.com.

Issued 09.2009

FAG 0009

Technical subject to change

© 2009 Schaeffler Automotive Aftermarket oHG

For further information:

Phone: +44 (0) 14 32 264 264*

Fax: +44 (0) 14 32 375 760

Info@LuK-AS.co.uk

www.Schaeffler-Aftermarket.com

* Calls from within the UK 08457 001100

FAG